

SUREBOND CLEANERS

TECHNICAL DATA SHEET

**PRODUCT DESCRIPTION:**

**Solvent Rx** is a ready-to-use product ideal for removing and repairing solvent based sealer and imperfections such as squeegee and roller marks, overlap streaks, over-application, overspray and trapped water vapor (white spots/cloudiness) on surfaces where a solvent based sealer was applied. It also can be used for cleaning tools and solvent-based sprayers.

**Solvent Rx is not appropriate for use with water based and silane/siloxane sealers.**

FEATURES	BENEFITS
<b>Repairs Imperfections</b>	<ul style="list-style-type: none"> <li>• May Eliminate the Need to Strip a Project with Sealer Imperfections</li> </ul>
<b>Removes Overspray &amp; Excess Sealer</b>	<ul style="list-style-type: none"> <li>• Improves the Appearance of a Surface with Over Applied Sealer</li> </ul>
<b>Solvent Based Sealer Stripper</b>	<ul style="list-style-type: none"> <li>• Strips Away Solvent Based Sealer without Surface Damage</li> </ul>
<b>Cleans Tools &amp; Sprayers</b>	<ul style="list-style-type: none"> <li>• Makes Clean Up Easy for Tools Used with Solvent Based Sealers</li> </ul>

**APPLICATIONS:**

**FOR USE WITH SOLVENT BASED SEALERS ONLY**

Repairs and removes excess solvent based sealer and imperfections. Can be used for cleaning tools and sprayers used for solvent based sealer application.

**PREPARATION/PRE-TESTING:**

When using Solvent Rx as a sealer stripper, it may be necessary to manage rinse water containing old sealer and Solvent Rx by reclamation to prevent run-off into storm sewer. Small scale projects can be dammed and residue removed with a shop vac. Large projects or volume of residue can be removed with a reclamation unit.

**TEST FIRST:** Before using Solvent Rx, test on a small inconspicuous area following the usage guidelines to determine the suitability for removing the desired sealer, repairing the imperfection and required dwell time needed for effectiveness. Dwell time will be determined by volume of sealer to be removed. Allow test area to dry thoroughly before evaluating final appearance and results.

**USAGE GUIDELINES:**

**FOR USE WITH SOLVENT BASED SEALERS**

When using Solvent Rx, wear protective nitrile gloves, clothing, and eye or face protection. It may be necessary to perform repeat applications for repair and removal effectiveness.

**REPAIR METHODS FOR SEALER IMPERFECTIONS:**

**Rinse Method** (for altering the sealer appearance without removing all of the sealer): Pour or spray Solvent Rx onto the solvent based sealer imperfection. Let dwell and keep wet with Solvent Rx for approximately 15 minutes (dwell time based on your pre-test). Do not touch the Solvent Rx on the surface when it is wet. Let dry naturally or use a blower or fan to speed up the drying process.

**Roller Method** (for removing or redistributing excess sealer without removing all of the sealer): Pour or spray Solvent Rx onto the solvent based sealer imperfection. Let dwell and keep wet with Solvent Rx for approximately 15 minutes (dwell time based on your pre-test). Roll a slit-foam roller over the imperfection to spread and/or remove excess solvent based sealer. Let dry naturally or use a blower or fan to speed up the drying process.

**Wipe Method** (for removing minor/superficial sealer imperfections in small areas such as roller marks or tire tracking): Pour or spray Solvent Rx onto a clean white rag. Blot, wipe or scrub the solvent based sealer imperfection with the Solvent Rx soaked rag. Let dry naturally or use a blower or fan to speed up the drying process.

**STRIPPING METHOD FOR SEALER REMOVAL:**

**Stripping Method:** (for sealer removal from the surface): Spray Solvent Rx onto a surface where a solvent based sealer needs to be removed. Let dwell and keep wet with Solvent Rx for approximately 15 minutes (dwell time based on your pre-test). Use a pressure washer with wand or flat surface cleaner to agitate and remove the Solvent Rx and sealer from the surface. Rinse thoroughly. (See 'Preparation' instructions regarding management of rinse water and Solvent Rx.) Let dry naturally or use a blower or fan to speed up the drying process.

**TOOL & SPRAYER CLEAN UP:**

**Tool Clean Up:** Soak tools in Solvent Rx (spray wands, nozzles, paint shields and other equipment). If necessary, scrub with stiff bristle brush. Let dry naturally.

**Sprayer Clean Up:** Empty sprayer of all remaining solvent based sealer. Pour Solvent Rx into sprayer and tighten lid. Shake sprayer several times and spray all of the Solvent Rx into a container for proper disposal. To clean the outside of the sprayer, pour Solvent Rx onto a clean rag and wipe the sprayer. Let the rag dry before disposing of it properly.

## SUREBOND CLEANERS

## TECHNICAL DATA SHEET

### PACKAGING:

Quart Containers: 12 quarts/case, 36 cases/pallet

Gallon Containers: 4 gallons/case, 36 cases/pallet

### STORAGE:

Store locked up in a cool, well-ventilated place.

### DISPOSAL:

Dispose of contents and container to appropriate waste site or reclaimer in accordance with all applicable laws, regulations and product characteristics at time of disposal.

### SHELF LIFE:

2 years when unopened and properly stored

### VOC:

871 g/L (Not for sale in California)

### PRECAUTIONARY INFORMATION:

#### DANGER - FLAMMABLE LIQUID & VAPOR

#### PREVENTION: KEEP OUT OF REACH OF CHILDREN

- Obtain special instructions before use
- Do not handle until all safety precautions have been read and understood
- Wear protective gloves, clothing, eye or face protection
- Keep away from heat, hot surfaces, sparks, open flames and other ignition sources
- No smoking
- Use explosion-proof electrical, ventilating, lighting and all material-handling equipment
- Use only non-sparking tools
- Take precautionary measures against static discharge
- Keep container tightly closed
- **Use only outdoors or in a well-ventilated area**
- Avoid release to the environment
- **Do not breathe vapor**
- Wash hands thoroughly after handling

### EMERGENCY & FIRST AID MEASURES:

Collect spillage. Get medical attention if you feel unwell.

**IF EXPOSED OR CONCERNED:** Get medical attention. **IF**

**INHALED:** Remove person to fresh air and keep comfortable for breathing. Call a POISON CENTER or physician if you feel unwell. **IF SWALLOWED:** Immediately call a POISON CENTER or

physician. Do NOT induce vomiting. **IF ON SKIN (or hair):** Take off immediately all contaminated clothing. Rinse skin with water or shower. If skin irritation occurs: Get medical attention. **IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical attention. **IN CASE OF FIRE:** Small Fire: Use steam, CO<sub>2</sub>, dry chemical or inert gas (e.g., nitrogen). Large Fire: Use foam, water fog or water spray

**SEE SAFETY DATA SHEET FOR COMPLETE INFORMATION.**

### WARRANTY:

SEK-Surebond warrants its products to substantially conform to its published specifications at the time of purchase. The foregoing is the sole limited warranty applicable to the products. **SEK-SUREBOND HEREBY DISCLAIMS ALL OTHER WARRANTIES OF ANY KIND OR NATURE, WHETHER EXPRESS, IMPLIED, OR STATUTORY, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR ANY OTHER WARRANTY OTHER THAN THE WARRANTY SET FORTH ABOVE.** The user is solely responsible for determining suitability of the products for their particular use. While the actual application of this product is out of the control of SEK-Surebond, it is recommended that the application guidelines be followed completely and accurately. SEK-Surebond's liability for any damage shall not exceed the purchase price of the product used, and it shall have no liability for consequential, incidental or punitive damages.

**SEK SUREBOND**  
HARDSCAPES *Done Right!*<sup>™</sup>

3925 Stern Ave. | St. Charles, IL 60174  
Email: info@sek.us.com | 800-932-3343

