




Formulated for Joints Up to 3/4"
Concrete & Clay Pavers • Natural Stone
Cast Stone • Porcelain Tile

PolySweep Estimated Coverage Per 50lb. Bag	
Joint Size	Area in Sq. Ft.
Up to 1/4"	50 - 75
1/4" - 1/2"	25 - 50
1/2" - 3/4"	15 - 25

Coverage will vary depending on shape, size & depth of pavers installed.

PolySweep Available Colors*



Color may vary due to the nature of aggregates and moisture content.



Formulated for Joints Up to 4"
Concrete & Clay Pavers • Natural Stone
Cast Stone • Porcelain Tile

X-Treme Wide Joint Estimated Coverage Per 50lb. Bag		
Paver Type	Joint Size	Area in Sq. Ft.
Standard	Up to 1/4"	50 - 75
Standard	1/2" - 3/4"	15 - 25
Natural Stone	Up to 2"	40 - 50
Natural Stone	2" - 4"	25 - 35

Coverage will vary depending on shape, size & depth of pavers installed.

X-Treme Wide Joint Available Colors*



Color may vary due to the nature of aggregates and moisture content.

*Color Availability May Vary By Region.



LIFETIME LIMITED WARRANTY

If any PolySweep product has been installed per SEK-Surebond instructions, and is proven to have a manufacturer defect, then SEK-Surebond will refund the Polysweep purchase price. SEK-Surebond will only be obligated for the refund of the PolySweep purchase price and will not be responsible/liable for any other costs. **See SEK-Surebond website for complete warranty details and restrictions. www.sek.us.com**

PACKAGING & STORAGE

Available in 50 lb. bags. 56 bags per pallet. Product must be stored in a dry location. Intact, covered pallets can be stored outdoors.

CAUTION

This product contains crystalline silica, which is known to the state of California to cause cancer. It may cause damage to lungs through prolonged or repeated exposure. This product causes skin irritation and serious eye irritation. **PREVENTION:** Obtain special instructions before use. Do not handle until all safety precautions have been read and understood. Wash any exposed body parts. Wear protective gloves, protective clothing, eye protection & face protection. **IF EXPOSED OR CONCERNED:** Get medical advice/attention. **IF ON SKIN:** Wash with plenty of water. Take off contaminated clothing and wash before reuse. **IF IN EYES:** Rinse continuously with water for several minutes. Remove contact lenses if present and easy to do. (SEE SAFETY DATA SHEET FOR COMPLETE INFORMATION)



800-932-3343

www.sek.us.com | www.sek.us.com



One Sand Does It All!
Residential & Commercial Applications
 Driveways, Walkways, Patios, Pool Decks & Concrete Overlays



FASTER STRONGER BETTER™

Concrete & Clay Pavers • Natural Stone
Cast Stone • Porcelain Tile

Clear Set Technology®

- ✓ Superior Strength
- ✓ No Portland Cement
- ✓ Original Haze Free Formula
- ✓ Lifetime Limited Warranty



MADE IN THE U.S.A.

PolySweep's Original Winning Formula: Check the Benefits That Stack Up

✓ HAZE FREE GUARANTEE

Guaranteed not to haze when following installation instructions.

✓ CLEAR SET TECHNOLOGY®

Advanced technology using native sands and high quality clear synthetic polymers that don't leave a haze.

✓ SUPERIOR STRENGTH

Creates a long term, semi-solid, flexible joint that resists cracking.

✓ NO PORTLAND CEMENT

Contains no portland cement which is often the cause of hazing and cracking.

✓ STRONGER SET UP

Superior cohesion characteristics on initial set up and after full cure.

✓ PREVENTS SAND LOSS

No sand erosion caused by rain and run-off.

✓ REDUCES OVERALL MAINTENANCE

Inhibits weed growth and deters insects.

✓ CAN BE USED ON CONCRETE OVERLAYS & PORCELAIN TILE


One product does it all – no need to buy separate formulations. See installation process for further instructions.

✓ PERFORMANCE NOT AFFECTED BY SALT AND DAMAGING DE-ICERS

✓ LIFETIME LIMITED WARRANTY



Testing Shows PolySweep Outperforms the Competition When it Comes to the Critical Characteristics that Matter Most.



Results based on extensive comparative tests performed from September 2013 through February 2014. Cohesion strength measured in tensile strength psi.

■ **Cohesion** – The testing indicates that PolySweep achieves superior cohesion versus the competition by a factor of 6 (180 psi VS 30 psi) within 12 hours of activation. PolySweep maintains superior cohesion performance at 24, 36, and 48 hours after activation. (See chart.)

■ **Adhesion** – The testing indicates PolySweep outperforms the competition in its adhesion characteristics. PolySweep demonstrated a superior ability versus the competition to adhere to pavers and natural stone which will result in a longer lasting, more stable joint.

■ **Set Up** – Set up is achieved when the polymeric sand has surpassed a cohesion threshold that will not allow heavy rain or strong wind to move it out of the joint. Don't be fooled when assessing set up. Harder is not an indication of good set up, cohesion is an indicator of good set up. PolySweep outperforms the competition in set up.

Installation Process for PolySweep & X-Treme Wide Joint PolySweep

INSTALLATION CONDITIONS:

- Prior to installation of Polysweep, make sure pavement surface is dry AND rain is not forecasted for 12 hours after installation.
- Install Polysweep when the average ambient air temperature is above 35 degrees for a minimum of 48 hours after installation.
- When applying Polysweep with natural stone, be sure the surface is free of any dust or stone residue, pre-rinsing stone if necessary. Allow surface to completely dry prior to applying Polysweep.
- Follow ICPI recommended best practices for installation, using ¾" modified stone base and concrete sand setting bed. See instructions below when using PolySweep on a concrete overlay.
- **Please see SEK-Surebond website for complete installation instructions.**

CAUTION:

- Do not apply water so fast as to flood the pavement or erode sand from paver joints.
- PolySweep is not designed for vertical applications and is not a substitute for mortar.
- Do not mix or dilute polymeric sand with any other product.

CURING:

Polysweep curing process is dependent on temperature and humidity level and could take up to 24 hours or longer. Cool, damp and overcast conditions will increase PolySweep set up time.

INSTALLATION INSTRUCTIONS:

- Distribute PolySweep evenly across surface. Sweep sand into joints until full. Do not push sand over surface for long distances.
- For Concrete Pavers: To consolidate sand into the joints, run vibratory compactor over the pavement. For Cast Stone or Natural Stone: Use a vibratory rubber roller or a rubber hammer and a piece of wood.
- Add additional sand into the joints if necessary. Repeat compaction. Do not overfill joints. Sand should be 1/8" below pavement surface.
- After joints are filled, remove excess product. Then use a leaf blower to remove any residual sand/dust from pavement.
- Using a hose, gently mist the pavement, allow water to absorb into joint. After 5 minutes repeat misting process 3, up to 4 times, gradually increasing volume of water each time. For optimal joint performance, the entire sand joint must be fully saturated.
- Any residual water caught in the texture of the pavement surface should be blown off with a leaf blower.

CONCRETE OVERLAY ADDITIONAL INSTRUCTIONS:

When using PolySweep on concrete overlays (pavers/stones installed directly on concrete), the concrete surface must have a minimum of 1% slope. Do not allow water to be trapped in the pavement system. Any water that enters the surface of concrete overlay applications must be allowed to escape the sand setting bed either at the outside perimeter or via drainage holes drilled thru the concrete. See SEK-Surebond website for detailed concrete overlay instructions.