




A PERMEABLE SOLUTION
FROM THE MAKERS OF
SnapEdge®

PERMEABLE PAVER RESTRAINT RESIDENTIAL

THE SOLUTION TO SECURING THE PERMEABLE PAVER EDGE




- Spikeless PICP Paver Restraint holds permeable pavers firmly in place
- Comes fully assembled with Geogrid anchor permanently attached to the SnapEdge® Paver Restraint
- Installs on top of the stone chip setting bed
- One piece design for straight and curved applications
- Integral section to section connector
- Edging is made of 100% recycled material 

Other Permeable Solutions available from SEK-Surebond include PermChip Granite Chips and SB-1000 PermStik Chip Stabilizer.

PERM EDGE®

INSTALLATION OUTLINE



- Excavate area the depth required to meet design criteria and extend 6" past (outside) the edge of the paving stones.
- Install soil separation fabric along the sides of the excavation with a minimum of 12" of additional fabric extending past the top of the excavation.
- Install stone base into excavated area.
 - 1st layer-Minimum of 6" thick ASTM NO. 2 open graded stone
 - 2nd layer-4" thick ASTM NO. 57 open graded stone
- Install stone setting bed on top of stone base.
 - 1.5-2" thick of ASTM NO. 8 or 9 aggregate
- Fold fabric over top of the setting bed and under PermEdge® and first paver. (See drawing above.)
- Install PermEdge®. Start on one side of pavement area.
 - Locate PermEdge® per design. Be certain that it sits on top of the soil separation fabric flap that lays on top of the setting stone.
 - Use 3/8" spikes to temporarily hold edging in place
 - Unfold grid and extend it full length into the pavement area. Be careful to lay grid evenly over setting bed stone, insuring there are no folds/wrinkles in the grid.
 - Installing the edging with a radius will require that back support of the PermEdge® be cut as well as the grid slit in even increments (suggested 12-18") perpendicular to the edging. Tighter radius will require shorter increments (more slits)
- Start along the PermEdge® installing the paving stones in the desired pattern.
 - Extend the field of pavers out from the first edge to approximately 6' away from the other desired edge. Stop laying pavers at this point.

- Locate 2nd edge per the module, spiking down PermEdge® temporarily.
 - Prepare fabric similarly to opposite side so it is on top of stone setting bed and will lay under PermEdge® and first paver.
- Once 2nd PermEdge® is located and secure, go back and continue to install paving stones towards second edge.
- Make any required paving stone cuts.
- Once all cuts are complete, finish installation.
 - Backfill PermEdge® with soil to the top of the pavement as soon as practical.
 - Compact stone with appropriate plate compactor
 - Fill pavement voids with PermChip Granite Chips or equivalent.
- Remove all temporary spikes from PermEdge®.

For more detailed instructions, please visit our website at www.sek.us.com



PACKAGING INFORMATION

GEOGRID AND EDGING PRE-ASSEMBLED BEFORE SHIPPING

PermEdge® Length	8'0"
Geogrid Anchor Length	4'
Full Pallet Contains	64 pcs

SEK SUREBOND
 HARDSCAPES *Done Right!*



800.932.3343 | www.sek.us.com